

Please use this list to identify horizontal pin setting on the Camlink Z1 Charger



Battery Model	Pin Setting 1	Pin Setting 2
BCF10	26	37
BCG10	27	36
BLB13	19	26
BLB2	15	27
BP1100S	19	24
BP214		
BP617	12	35
BP760	11.5	18
BP780	16.5	25
BP85ST	7	14
CA1L	17	34
CA2L	17	31
CA315	25	31
CA3L	15	35
CA406/422	22	31
CA4L	30	35
CA511/522/535	23	36
CA54	16	34
CA5L	12	20
CA608	12	35
CA6L	10	17
CA7L	22	36.5
CA914/940/970	5	35
CALPE5	25	30
CGAS001		
CGAS003	23.5	32.5
CGAS007	26.5	36
CGAS307		
CGRS101	17	29
CGRS602/002/001	19	26
CNP100	15	31
CNP50	25	35
CNP70	21	33
DBL20	24	35
DBL40	11	21
DMWBCE10	27	35
DRLB4	13	34
DSS1/SSF11/SSF21	26	38
DVBP1	4	37
DVBP120/220/320/07/14/21	19	26
ENEL	17	35
ENEL11	10	35

ENEL11	20	30
ENEL12	27	36
ENEL2	17	28
ENEL3	6	19
ENEL3E	24	38
ENEL4	10	18
ENEL8	22	34
F11/J101	23	38
FE1	24	35
FF70		
FLNP120	21	34
FLNP140	12	26
FLNP150	24	38
FLNP30	29	37
FLNP40	22	35
FLNP50	23	34
FLNP95	21	35
J107/J114	12	29
J200	15	29
J207/214	5	35
J306/312	16	35
J37		
J408/416/428	10	35
J507/514	22	34
J607	6	37
J707/733	12	33
J712	24	38
J907	14	38
K05001	20	35
KO7000	15	24
KO7002	24	33
KO8000	26	34
LIP10	21	38
LIP12		
LIP8		
MNP200	23	36
MNP400	18	36
MNP700	29	37
MNP900	24	34
NP100/200/300		
NP550/750/950	5	37
NPFH50/70/100	21	26
OL1	10	22
OL30	22	36
OL50	12	22
SBD1	25	35
SBL70/11	7	35
SBLH82	27	33
SBLSM80/160	15	36
SBP90/120	8	34

SBP90/120	8	34
SFP50/70/90	21	27
SFR1	23	35
SFT1	23	35
SFT1	23	35
SGB1974	6	36
SH221/222/442/441		
SH225/455		
SLB07A	30	35
SLB1137C	24	29
SLB1237	7	28
SM50/70/90	5	36
SMBL110/22/160/32/420	6	36
VMNP500L/27	4	37